



Hire and Rental Industry Association Ltd

Product Safety Assessment Sheet

PLANT INFORMATION

PSA Ref #: 00010

Model No: EARLEX SM5

Plant Name: STEAM WALLPAPER STRIPPER SM5

Manufacturer: Crommelins Machinery WA

Manufacturer's Website: www.crommelins.com.au

Web Link for Plant: www.crommelins.com.au

Mandatory Personal Protective Equipment:



Eye Protection



Foot Protection



Protective Clothing



THE CROMMELIN GROUP

RISK ASSESSMENT INFORMATION

Operator Competency: Plant Licence Not Required

Potential Hazard(s)	Risk Level	Control Measure(s)
Coming into contact with high temperature, steam, or hot parts.	Medium/Low	<ul style="list-style-type: none"> The plant is provided with a protective cover over the steam tank. The tank is provided with a pressure release cap. Allow to cool before opening and filling the steam/water tank. Release the pressure relief cap fully before completely removing the tank cap. Do not touch the steam plate or other hot parts. Warning label on plant. Wear eye protection to safeguard against possible droplets of hot water or steam coming of the steam plate.
Electrical hazard.	Medium/Low	<ul style="list-style-type: none"> Do not allow steam/water to come into contact with power supply or power outlet. Do not use power outlet on walls being stripped for supply of electricity to the unit. Cover any power points likely to be affected by moisture running down the walls. Ensure equipment is tested/tagged for compliance with electrical safety testing requirements. Use a power supply protected by a safety switch.
Slip/Fall	Medium/Low	<ul style="list-style-type: none"> Maintain a sure footing and a stable platform when working overhead. Wear appropriate footwear when working in slippery or wet areas.

Customer Identified Hazard(s)

Key Operating Instructions

Fill with water only to the maximum indicated level.

Wait until the steam is flowing freely before commencing operation.

Use only H/D 15amp rated extension lead.

Connect to a power supply protected by a safety switch.

Plug in to a power source away from the area to be worked on.

Ensure cables and plugs are not in contact with wet areas.

To refill, let the unit cool down, release the pressure relief cap fully before completely removing, then fill to indicated level.

Maintain a sure footing and a stable platform if working above the floor level.

Wear appropriate footwear when working in slippery or wet conditions.

Please refer to the User Guide and Operator's Manual for Operating Instructions

The Safety Information on this assessment has been developed for the Hire and Rental Industry to assist in the safe operation of this equipment.

This information contains general information only and should not be relied upon as a substitute for professional advice, which the user should seek before operating.

Once printed this is an uncontrolled copy.